


## ONE-OFF WEIGHING –INSTRUCTIONS



Terminal display when the boom is closed and there is no truck on the weighbridge.



WEIGHING

License no

Weights  
1.  kg

Info

type info  
Accept weighing with ENTER

When the vehicle has been identified, the registration number will be displayed, and the driver can see the real-time total weight of the vehicle at the right bottom edge of the display. The driver can type additional information in the blank field by using the keys, and accept the weighing by pressing ENTER, and the device will print out a weighing receipt. The receipt can be reprinted by pressing the key “P”.

*If you have problems with printing the receipt, contact the Gate Control Room:*

*05-2605081*